

GLOSSARY

BUTLER DEFINITIONS

PART

A singular item.

COMPONENT

A combination of parts fitted together.

THE BUTLER MACHINE, MACHINE

The combination of components as shown on schematic.

THE BUTLER SYSTEM, THE BUTLER, SYSTEM

The combination of components as shown on schematic, as well as all Butler-equipped tanks, reels, signage, trim, etc.

THE UNIT, UNIT

The combination of the Butler System and the vehicle itself.

THE BUTLER CORPORATION, BUTLER, BUTLER'S, THE BUTLER FACTORY, FACTORY, FACILITY, WE, US, OUR

Refers to The Butler Corporation as located at 251 Moody St., Ludlow, Massachusetts.

WARRANTY

The warranty as described in the Butler System Warranty Booklet.

PROCEDURE

A sequence of instructions that must be followed from beginning to end.

SDS

Safety Data Sheet.

TOOL

A wand, upholstery tool, simulator nozzle, etc.

NUMBERS

Numbers (example: 1010) indicate parts and components on schematic.

VEHICLE MANUFACTURER DEFINITIONS

GROSS VEHICLE WEIGHT (GVW)

GVW is the actual weight of the entire vehicle and its contents, including fuel and occupants.

GROSS VEHICLE WEIGHT RATING (GVWR)

GVWR is the maximum amount of weight allowable, as established by the manufacturer for the vehicle, equipment, payload, fuel and occupants.

PAYLOAD

Maximum allowable weight of cargo to be carried in a vehicle, including occupants. Computed by subtracting curb weight from GVWR.

GROSS PAYLOAD

Amount of cargo a vehicle is rated to carry including the weight of options, equipment and occupants.

NET PAYLOAD

Amount of cargo a vehicle is rated to carry less the weight of options, bodies, equipment and occupants.

GROSS COMBINATION WEIGHT RATING (GCWR)

GCWR is the maximum amount of weight allowable, as established by the manufacturer for the vehicle, trailer, equipment, payload, fuel and occupants.